


ShoreLite Shield 2.5

Built strong for the ditch, but light to lift



Just Pin the spreaders to the side walls. This is a trench box that is like the contractors use, but is light enough to lift and place in the trench with a tractor back hoe or mini excavator.

Be Ready to transport on your trailer then just lift and drop into the trench and start working.

Configure a trench box from a full line of options available that will meet the requirements of your people.

Be Ready and stage the box on your trailer. You will be ready to take care of emergency repairs quickly.


Accessories

The ShoreLite shield comes standard with:

- **Steel tamping blocks**
- **Rotating rigging points for uniform lifting**
- **Movable sockets at multiple locations for better clearance**
- **Stacking sockets allows fast and easy stacking**
- **ShoreLite Shield Drop On Adapter hooks onto any ShoreLite Shield panel creating a dropon**

Available is steel cutting bars to protect the bottom of the side wall.

Call Kundel customer service for help in configuring a ShoreLite Shield for you that meets the way you want to do the work. Call and ask our construction experienced staff questions, who are ready to help you with your next repair or pipe installation.



Simple and Easy Assembly

You can have the pre-engineered components assembled just for you. It's like buying a pizza!

Options to configure

- *Simple with side walls and fixed spreaders
- *Variable width with a standard spreader adjuster
- *Fixed width, closed end or ends for added safety
- *Variable width, closed end or ends, for flexible with safety
- *Hydraulic or screw strut adjustable width
- *Holes in the side wall for tapping
- *Tandem lugs for shoring a longer area
- *Stacking tubes for going deeper
- *Hold the box off the bottom of the trench
- *Rubber-wheeled axle for rolling the box ahead

Note: ShoreLite modular system must be assembled before use.



ShoreLite Shield 2.5

(Spreader not included)

Steel Spreader

(Adjusters must be used with Spreader)

mfg no.	size	wgt.	"A"	"B"	"C"
SLAS-4X6	4' X 6'	380	34	19	16
SLAS-4X8	4' X 8'	450	31	17	13
SLAS-4X10	4' X 10'	515	29	15	11
SLAS-4X12	4' X 12'	580	26	13	9
SLAS-6X6	6' X 6'	570	34	19	16
SLAS-6X8	6' X 8'	675	31	17	13
SLAS-6X10	6' X 10'	773	28	15	11
SLAS-6X12	6' X 12'	870	26	13	9
SLAS-8X6	8' X 6'	760	34	19	16
SLAS-8X8	8' X 8'	900	31	17	13
SLAS-8X10	8' X 10'	1030	29	15	11
SLAS-8X12	8' X 12'	1166	26	13	9

mfg. no.	length	wgt.
A-1024	24"	60
A-1030	30"	72
A-1036	36"	88
A-1042	42"	104
A-1048	48"	120
A-1054	54"	136
A-1060	60"	148
A-1066	66"	164
A-1072	72"	180
A-1078	78"	196
A-1084	84"	212
A-1090	90"	224
A-1096	96"	240
A-ADJ	6" - 24"	90

Spreader Sold Separately

Accessories

- | | |
|-------------------------|------------------------|
| Spreader | Drop-ons |
| Spreader adjusters | Stacking tubes |
| Spreader beams | Tandem lugs and plates |
| Spreader beam adjusters | Steel Knife bottom |
| Hydraulic struts | Square connectors |
| Screw struts | Leg Kite |
| V-Panel | Wheeled kit |
| Timber Shore plank | Rigging |

Note;
 There are many more accessories available. Just call Kundel customer service and describe what you want or tell us your problems you want to overcome. Unlike a pizza, this unit will last many, many years, and you can re-configure at any time.



Call or visit us online for a complete list of accessories
ALL INFORMATION SUBJECT TO CHANGE WITHOUT NOTICE.